FOODIE KITCHEN SCALE

Specifications

· Capacity: 5000 grams / 11 pounds / 176 ounce

· Increment: 1 gram, 0.1 ounce (1/10th oz.)

· Weight modes (ii): Grams, Pounds, Ounces

· Water modes (¿): Millilitre (ml.), Fluid ounce (fl'oz)

· Milk modes (為): Millilitre (ml.), Fluid ounce (fl'oz)

· Auto shut off: Turns off after 2 minutes of non-use

· Low battery and overload indication

· Power source: 2 x AAA 1.5V

O-button: ON / OFF / Tare

UNIT-button: Shuffle between modes

ON/OFF - Calibration

Press the **O**-button to turn on. "O" is displayed once the scale is ready for use. Press and hold the **O**-button to turn off the scale.

Units

To change measuring units, press the UNIT-button to shuffle between different modes.

Weighing individual portions

To weigh more than one portion, press O-button (TARE) to reset the display between each of them.

Error indication

"Lo" means low battery.

"Err" means overloaded.

"unSt" means unstable on surface.

For more detailed instructions go to RIG-TIG.com

